

127.1 127


4.3

Fig. 7/1: Fit the contact system back-to-front on the thin end of the arbor and slide it onto the thicker shank area

4.3 Contact system

127 Arbor

127.1 Journal



4.6

4.2

(4.5)

4.3

4.4

127

Fig. 7/2: Slide the contact system over from the arbor onto the isolating contact arm and allow it to engage there

4.2 Contact arm

4.3 Contact system

4.4 Internal tension spring

4.5 Hexagon socket head screw

127 Arbor